

Installation Instructions for 10432

Auxiliary Fuse Block

3-Circuit

1. Use the bolts provided in the kit to mount panel in desired location.
2. Use wire (Yellow 16 Ga.) to connect to an ignition hot terminal on your existing fuse panel. Use the fuse tap and blue push on terminal provided in the kit.
3. Connect wire (Black marked Ground) to a good clean Ground on chassis.
4. Connect wire (Red 10 Ga.) to the AUX. Side of the breaker provided in the kit. Connect the BAT. Side of the breaker to the positive side of your battery. Two # 10 ring terminals and 3/8" ring terminal provided in the kit.
5. You can now connect you accessory lead wires to your desired location. (Blue , Lt Green and Orange)

