

Installation Instructions for 40349 Spark Plug Boot Heat Shrink Sleeve

Installation Instructions:

1. Cut all spark plug wires to length and slide 2 sleeves over the spark plug wire. If you only wish to seal one end of each wire use only 1 sleeve.
2. Finish assembling and terminating the spark plug wire ends
3. Clean the surface areas that will be sealed with the sleeve
4. Slide the shrink sleeve halfway over molded boot and halfway over the spark plug wire.
5. Use a heat gun, JEGS 555-W50076 or equal to apply heat to the sleeves once you have them in place. Heat thoroughly until shrinkage is complete and a few seconds after that to make sure that the sleeve will hold after cooling.
6. If installing sleeves on the distributor end of the wire, make sure the boots are in the proper position before installing the sleeve and applying heat. Recommended procedure is to first lock the terminal and boot onto its proper place on the distributor cap then slide the sleeve over the boot and wire. Finally apply heat with the wire still on the cap so as to not disturb the relationship between the wire and boot. Heat will not damage the distributor cap.
7. Once the sleeve is on, you will not be able to reposition the terminal inside the boot, so be sure before applying the heat. After cooling the wire can be removed from the distributor cap without problem and you can move on to the next wire.



1-800-345-4545 jeps.com